

Alcatel-Lucent OmniTouch 8082 My IC Phone

OmniPCX Office Rich Communication Edition User manual



Introduction

Thank you for choosing an Alcatel-Lucent phone.

This model offers enhanced ergonomical features for more effective communication.

Its innovative and high-quality design will improve your corporate communications and allow access to a variety of services.

How to use this guide

• Actions



Lift the receiver



Hang up

• Keypad



Numeric keypad.



Alphabetic keypad

Your phone has a touch screen. You can interact with your phone by touching the screen. The following symbols describe the possible actions on the touch screen.



Press the touch screen once



Press the touch screen twice



Move your finger while keeping it in contact with the screen



• Audio keys



Handsfree/Loudspeaker



Intercom and Mute key



Phone key to increase ring, handset or speaker volume



Phone key to decrease ring, handset or speaker volume

• Other phone keys



User information and forward management



Phone events



Keypad



Alarms



Homepage

	Getting to know your telephone	p. 8
1.	Getting to know your telephone	p. 10
	1.1 Phone description	p. 10
	1.2 Screen description	p. 11
	1.3 Personal area	p. 11
	1.4 Notifications area	p. 12
	1.5 Date, time and connectivity area	p. 12
	1.6 Active area	p. 12
	1.7 Connectivity icons	p. 13
	1.8 IP Touch Bluetooth® Wireless handset	p. 14
2.	Using your telephone	p. 15
	2.1 Make a call	p. 15
	2.2 Make a call using the personal phone book (Contacts)	p. 15
	2.3 Using call by name	p. 16
	2.4 Call from call log	p. 16
	2.5 call back one of the last numbers dialled	p. 16
	2.6 Call a contact from the favorites application (Favorites)	p. 17
	2.7 Answer the call	p. 17
	2.8 Ignore call	p. 17
	2.9 Forward an incoming call	p. 18
	2.10 Using the telephone in "Hands free" mode	p. 18
	2.11 Receiving intercom calls	p. 19
	2.12 Mask my identity	p. 19
	2.13 Contact call log	p. 19
	2.14 Customize the call log	p. 20
	2.15 Delete one call log event	p. 20
	2.16 Delete events from the call log	p. 21
3.	During a conversation	p. 22
	3.1 Putting a caller on hold	p. 22
	3.2 Calling a second person during a conversation	p. 22
	3.3 Switching between calls (Broker call)	p. 22
	3.4 Transferring a call	p. 23
	3.5 Three-party conference	p. 23
	3.6 Mute, so that your correspondent cannot hear you	p. 23
	3.7 Voice frequency	p. 24
	3.8 Recording the current conversation	p. 24
4.	Contacts management	p. 25
	4.1 Define a contact	p. 25
	4.2 Add a contact from the call log	p. 25
	4.3 Make a call using the personal phone book (Contacts)	p. 25
	4.4 Modify a contact	p. 25
	4.5 Delete a contact	p. 26
	4.6 Define a contact as a favorite (Favorites)	p. 26
5.	Keep in touch	p. 27
	5.1 Details on your phone (number, name, etc.)	p. 27
	5.2 Define a forward	p. 27
	5.3 Activate a predefined forward	p. 28
	5.4 Immediate forward to voice mailbox	p. 28
	5.5 Your visual voice mail	p. 29
	5.6 cancel the forwarding	p. 29
	5.7 Modify the forwarding	p. 30
	5.8 Delete a forward	p. 30
6.	Keypad	p. 31
	6.1 Change the keyboard type	p. 31
	6.2 Delete a character	p. 31
	6.3 Write in uppercase	p. 31
	6.4 Write a number	p. 32
	6.5 Write special characters	p. 32

Programming your telephone	p. 33
7.1 Define the phone language	p. 33
7.2 Favorites	p. 33
7.3 Lock / unlock your telephone	p. 34
7.4 Adjusting the audio functions	p. 35
7.5 activate/deactivate silent mode	p. 35
7.6 Ring tones	p. 35
7.7 Progressive ringing	p. 36
7.8 Adjusting the ringer volume	p. 36
7.9 Adjust ringer volume while a call arrives	p. 36
7.10 Adjust the loudspeaker and the handset volume	p. 36
7.11 Activate/deactivate key vibration	p. 37
7.12 Activating headset mode	p. 37
7.13 Install a bluetooth device (pairing)	p. 38
7.14 Hearing aid kit	p. 39
7.15 Activate the magnifying glass feature	p. 39
7.16 Magnifying glass	p. 39
7.17 Set an alarm	p. 40
7.18 File Manager	p. 40
7.19 Delete a file	p. 40
7.20 Rename a file	p. 41
7.21 Copy a file from the external storage device to the phones internal memory	p. 41
7.22 Listen to an audio file	p. 41
7.23 Play all audio files	p. 42
7.24 Phone wallpaper	p. 42
7.25 Phone screensaver	p. 43
7.26 Customize the user picture	p. 44
7.27 Configure your homepage	p. 44
7.28 Change the theme of your phone	p. 46
Guarantee and clauses	p. 47

- **LED**
 - Arrival of a new call (Flashing)

This area displays time, date, connectivity and customization information (wake-up on, intercom mode on)

In idle state
This area displays information on the latest telephone events such as missed calls, callback requests, messages, etc.

During a call:
The name of your caller and the status of the call (ongoing, on hold, incoming call) are displayed in this area. Pressing on this area during the conversation takes you back to the call screen.

This area displays time, date, connectivity and customization information (wake-up on, intercom mode on)

Handset

Socket for connecting headphones or a Hands-free / Loudspeaker unit



- **Audio keys**
 - Hang-up key::** to terminate a call.
 - Hang up key:** to answer a call.
 - Hands-free/Loudspeaker Key::** to make or answer a call without lifting the receiver.
 - Mute key**
During a conversation, press the Mute key to stop your caller from hearing you.
 - To adjust the loudspeaker or handset volume up or down**

■ **Alpha-numerical keypad**
The alpha-numerical is automatically displayed when you select a text zone or when you select the "alpha-numeric keyboard" key.



- Display the keyboard on the screen
- CAPS** Write in uppercase
 - Press once: uppercase mode for the next character entered only.
 - Press twice: uppercase mode for all characters entered.
- NUM** Write a number
 - Press once: numerical mode for the next digit only.
 - Press twice: numerical mode for all digits.
- Write special characters.
When this key is enabled (light is on), you can write special characters associated with a selected character.

■ **Connectivity icons**

-  **Headset connected**
-  **Silent mode activated**
-  **Bluetooth device connected**
-  **Alarm set**
-  **Telephone locked**

■ **Navigation**

The phone's Homepage can be in standard or preview mode. Scroll down or up your finger to get the page or menus vertically scrolling, or scroll right or left to get the page horizontally scrolling.




Homepage in standard mode

Homepage in preview mode

-  Make your selection by pressing on the screen.
-  Go to next screen.
-  Back to previous screen.
-  Back to homepage.

■ **Application**

The homepage in standard mode and the applications bar on the homepage in preview mode allow you to access the phone applications.



-  Scroll applications to get the desired application.
-  Press the application button to access to the application.

■ **Features key**

-  **Forward**
The forward key is blue when a forward is activated.
-  **Alarms**
This key lights blue when there is a wake-up alarm.
Press this key to access the call application. This key flashes if there are call events that have not been picked up (unanswered calls blinking in case of non consulted communication events such as missed calls, callback requests, new voice message, etc.).

1.1 Phone description



- 1 A sensitive LED wide screen.
- 2 Quick access to the main phones features.
- 3 A bluetooth handset for optimized communication.
- 4 A wide speaker for optimized sound.
- 5 An adjustable and stable foot.
- 6 Good connectivity to allow phone extensions.
 - A 10/100/1,000 Ethernet connection to connect to enterprise networks and a PC
 - Bluetooth
 - 2 USB connectors
 - 1 mini-USB connector for a keyboard
 - 1 RJ9 connector for a corded handset
 - One 3.5 mm headset connector

1.2 Screen description



Homepage in preview mode

Homepage in standard mode

- 1 Personal area**

This area displays information on the phones user (last name, first name, number, avatar, telephone status, forward, etc.).
- 2 Notifications area**

In idle state
This area displays information on the latest telephone events such as missed calls, callback requests, messages, etc.
During a call:
The name of your caller and the status of the call (ongoing, on hold, incoming call) are displayed in this area. Pressing on this area during the conversation takes you back to the call screen.
- 3 Date, time and connectivity area**

This area displays time, date, connectivity and customization information (wake-up on, intercom mode on).
- 4 Active area**

This area is reserved for running applications and for previews of applications selected by the user.
- 5 Applications area (Homepage in preview mode)**

This area allows access to all set applications and to different features of the running application
- 6 Applications area (Homepage in standard mode)**

You can access your phone applications from this area. Press the application button to access the application
Once you run an application, the display is the same as the preview mode display

1.3 Personal area

This area displays information on the phones user (last name, first name, number, avatar, telephone status, forward, etc.).

There are 2 parts :



Routing

Access forward programming and configuration functions



UserInfo

Information about the user



Select this area to access the user parameters and status of the phone

1.4 Notifications area

In idle state :

This area displays information on the latest telephone events such as missed calls, callback requests, messages, etc.

During a call:

The name of your caller and the status of the call (ongoing, on hold, incoming call) are displayed in this area. Pressing on this area during the conversation takes you back to the call screen.

■ Call status

	Incoming call
	Ongoing call
	Call on hold
	Three-party conference

1.5 Date, time and connectivity area

This area displays time, date, connectivity and customization information (wake-up on, intercom mode on).

1.6 Active area

This area is reserved for running applications and for previews of applications selected by the user. When you start an application, it is displayed in the active zone. If no application has been launched, the active zone displays the application previews that you have preset on the homepage. One application preview allows you to view this application information and easily access it. You can view all previews of the homepage by a horizontal screen scrolling.

■ Add or delete an application on the homepage

	Select the application Settings
	Application
	Select the application that you want to add to the homepage or delete from the homepage
	Activate or deactivate preview mode
	Back to homepage

1.7 Connectivity icons


	No Ethernet connections
	No VoIP connection
	No connection to the communication server
	Security mode
	Storage device connected to USB port
	Bluetooth device pairing in progress
	Bluetooth device connected (Other than your Bluetooth handset)
	Bluetooth device not connected
	Headset plugged in
	Wake-up feature activated
	Silent ring activated
	Intercom mode

 When the connection is correctly set up, the icon is not displayed on the phone

1.8 IP Touch Bluetooth® Wireless handset

LED

Off: operating normally.
 Blinking green: in communication.
 Green steady: handset charging .
 Orange flashing: battery charge low or handset outside coverage zone .
 Orange steady: malfunction .



Off-hook/On-hook and Volume/ Mute keys

Off-hook/On-hook: press this key to take or terminate a call

Volume/Mute:


- short successive presses to change the handset volume level (3 levels)
- long press to activate or deactivate mute mode

Location of the batteries



If the Bluetooth® handset is on its base, you do not need to press the Off-hook/ On-hook key to take or terminate the call. Just off-hook/on-hook the Bluetooth® handset

• Installing or replacing the Bluetooth® handset battery



• Installing or replacing the Bluetooth® handset battery

①	• Lift up the battery cover
②	• Slide out the battery holding part



The battery recharges when the Bluetooth handset is on its base.

2.1 Make a call



Take the handset off the hook

OR



Press the phones keyboard key

OR



Hands-free key

OR



Dialer

OR



Off-hook key on the Bluetooth handset



Dial the number for your call



Call



To make an external call, dial the outside line access code before dialing your contacts number (0 is the default code for an outside line)

• End the call



Hang up the handset

OR



End call

OR



On-hook key on the Bluetooth handset

2.2 Make a call using the personal phone book (Contacts)



Select the application
Contacts



Select the contact to call

Information regarding your contact is displayed on the screen



Press the call icon to call your contact



If there are several numbers for the same contact, select the desired number

2.3 Using call by name



Search



Enter the first letters of your contacts name



Ok

The names of contacts matching your search criteria are automatically displayed on the screen



Call your contact by choosing them in the list



If you wish you can also display your contacts complete file

2.4 Call from call log

All incoming, outgoing, missed or unanswered calls are displayed in the call log. You can call back from your phone call log.



Select the application

History



Select the contact to call



Call



If there are several numbers for the same contact, select the desired number.



You can also access the feature by selecting the application preview History

2.5 call back one of the last numbers dialled



Select the application

History



From the call log, select one of the last numbers dialed



Answered outgoing call



Unanswered outgoing call

Call



You can also access the feature by selecting the application preview History

2.6 Call a contact from the favorites application (Favorites)

Favorites : This application contains favorite contacts that you have selected in your personal directory.



Select the application
Favorites

All contacts defined as a favorite are displayed



Select the contact to call



Call



If there are several numbers for the same contact, select the desired number.



You can also access the feature by selecting the application preview Favorites



Refer to chapter: "Define a contact as a favorite "

2.7 Answer the call



Answer call

OR



Take the handset off the hook

OR



Hands-free key

OR



Off-hook key on the Bluetooth handset

• End the call



Hang up the handset

OR



End call

OR



Off-hook key on the Bluetooth handset

2.8 Ignore call

A call is received:



Ignore

Your phone no longer rings but your caller still hears the ringing tone



You can still answer the call after you have ignored it

2.9 Forward an incoming call

A call is received: your telephone rings.

■ Forward to voicemail



Deflect to VM

The call is directly forwarded to your voice mail

■ Forward to another number



Deflect

call the recipient of the transfer



Search

OR



Select the recipient from the call log

The call is immediately forwarded

2.10 Using the telephone in "Hands free" mode



You are in communication

Hands-free key

Select the desired audio mode:



Handfree



Speaker (Group Listening)



Handset

• To take the call back with the handset



Take the handset off the hook

OR



Handset

OR



Off-hook key on the Bluetooth handset

• To go back to "handsfree" mode



Press the "handsfree" key again
You can hang-up the handset

2.11 Receiving intercom calls

You can answer a call without lifting the receiver. When you receive a call, you are automatically connected in hands-free mode. The identity of the caller is displayed on the screen

• To

	Select the application Settings
	Application
	Telephony
	Interphony Yes / No

2.12 Mask my identity

You can hide your identity before sending your call.

	Select the application Settings
	Application
	Telephony
	Hide identity Yes / No
	Back to homepage

2.13 Contact call log

You can display your contacts call details (received calls, missed calls, callback requests, etc.).

	Select the application History
	Select the recipient from the call log
	History List your contacts calls (outgoing, incoming, missed, etc.) The associated LED is on: the feature is enabled



You can also access the feature by selecting the application preview History

2.14 Customize the call log

You can filter the calls displayed in the call log according to their type: missed calls, callback requests, received calls, etc.

	Select the application History
	Filter
	Select the call types that you want to display: <ul style="list-style-type: none">• All : all calls• Missed call : Unanswered incoming calls • Vicemail : Voice messages • Call back : Callback requests 
	Back
	Call log customization is active

 The filter remains active once you have left the application.

 You can also access the feature by selecting the application preview History

• Display all calls


	Filter
	All
	Back

2.15 Delete one call log event

	Select the application History
	Press the desired event
	Delete

 You can also access the feature by selecting the application preview History

2.16 Delete events from the call log



The image shows a vertical list of icons on the left side of a call log interface, each corresponding to a step in the deletion process:

-  Select the application **History**
-  **Delete all**
-  Select the type of events to be deleted
 - **All** : all calls
 - **Missed call** : Unanswered incoming calls 
 - **Voicemail** : Voice messages 
 - **Call back** : Callback requests 
-  Confirm deletion of all call log events : **Delete**

 If your call log contains unread events, a warning message is displayed on the screen

 If a filter is activated, you will only be able to delete events sorted by the filter

 You can also access the feature by selecting the application preview History

3.1 Putting a caller on hold



You are in communication

On hold

Your call is placed on hold

Your caller hears on-hold music until you pick the call up again

• Recover the correspondent on hold



Select the caller on hold from the call log or the notification area

OR



Retrieve

You are back on the call with your caller

3.2 Calling a second person during a conversation



You are in communication.

Dialer

Call the second person :

Dial the number for your call



OR

From the dialpad you can call the second party by directly dialing the number or through the call log (history), the contacts, the search by name or the favorites features :



Search



Contacts



Favorites



Call

The first call is on hold

3.3 Switching between calls (Broker call)



You are in communication with a first correspondent

A second correspondent is on hold

Switch from one caller to another by selecting the caller on hold in the call log

You are in communication with the second contact : first call is automatically placed on hold

3.4 Transferring a call

During a conversation, to transfer the call to another number:

- You are in communication with a first correspondent



Call the recipient of the transfer



Transfer

The two correspondents are connected

- You are in communication with a first correspondent
You want to connect the first caller with the second.



Transfer

The two correspondents are connected

3.5 Three-party conference



You are in communication with a first correspondent

Conference

You are in conference mode

During the conversation, you can:



End conf

Hang up on all correspondents

3.6 Mute, so that your correspondent cannot hear you

During the call, you do not wish your caller to hear you.



Press your phone "Mute" key

"Mute" mode is activated (The key is blue)

Your caller can no longer hear you



Press the key again to go back to normal mode

OR



Long press on the "Mute" key on the IP Touch Wireless handset

Press the key again to go back to normal mode

3.7 Voice frequency

During a conversation you sometimes have to send DTMF signals, such as with a voice server, an automated attendant or a remotely consulted answering machine.



DTMF



OR



Enter the requested codes

3.8 Recording the current conversation

When you are on a call with one or more callers, you can record the conversation.



To record the conversation during communication:

Record

Recording in progress...



You can pause, resume or stop the recording at any time

Pause



Resume



Stop



The user must have the appropriate rights to use this feature

4.1 Define a contact

-  Select the application
Contacts
-  **Add new contact**
-  Fill in the contact file.
You must provide at least a last name.
-  **Save Contact**

 For an external number, enter the number directly without the outside line access code. Please use the following (canonical) format: +33 390670000.

4.2 Add a contact from the call log

-  Select the application
History
-  Select the correspondent
-  **Add**
-  Fill in the contact file
-  **Save Contact**

4.3 Make a call using the personal phone book (Contacts)

-  Select the application
Contacts
-  **Select the contact to call**
Information regarding your contact is displayed on the screen
-  Press the call icon to call your contact

 If there are several numbers for the same contact, select the desired number

4.4 Modify a contact

-  Select the application
Contacts
-  Select the contact to modify
-  **Edit**
-  Fill in the contact file
-  **Save Contact**

 You can modify a contact while you are on a call

4.5 Delete a contact

	Select the application Contacts Select the contact to delete
	Delete Delete Contact ?
	Yes

4.6 Define a contact as a favorite (Favorites)

Most frequently called contacts can be defined as a favorite. Favorite contacts are displayed in the application Favorites.

	Select the application Contacts
	Select the contact to add to favorites
	Favorites The contact has been added to Favorites The key associated light is on

 The green light indicates that the contact has been assigned to Favorites

- To remove a contact from Favorites

	Favorites The feature associated led goes off
---	---

5.1 Details on your phone (number, name, etc.)

You want to know all of your phones information, such as your phone number or your phones forward status,.



Press the forward key

OR



Press your information area in the top left corner of the screen



UserInfo

5.2 Define a forward

Your phone allows you to define different types of forwards.

- **Immediate forward to...**
All your calls are immediately forwarded to an other set or voicemail
- **Forward if busy**
All your calls are forwarded to another set or voicemail when you are already on the line



Press the forward key

OR



Press your information area in the top left corner of the screen



Routing



Add routing



Select the forward type to program

- **Immediate forward to...**
- **Forward if busy**



Next

■ Forward your calls to another set



Other



Enter the forward destination number



Validate

The forward is added to the list of predefined forwards
You can activate it immediately or later

■ Forward your calls to voicemail



Voicemail



Save

Save the forward
The forward is added to the list of predefined forwards
You can activate it immediately or later

5.3 Activate a predefined forward

Your phone allows you to activate predefined forwards or forwards that you created previously.

	Press the forward key
	OR
	Press your information area in the top left corner of the screen
	Routing
	The predefined forwards list is displayed on the screen
	Select the desired forward
	Forward is activated (The key is blue)
	The activated feature is indicated in your personal information area in the top left corner of the screen
	Back to homepage

 The forward key is not lit when no forward is activated.

5.4 Immediate forward to voice mailbox

 You have to define the forward before using it

	Press the forward key
	Voicemail
	Forward is activated (The key is blue)
	The activated feature is indicated in your personal information area in the top left corner of the screen

 The forward key is not lit when no forward is activated.

 When you create a forward, it will be added to the list of available forwards so that you can reuse it.

5.5 Your visual voice mail

Visual voicemail displays and manages voicemail messages left by your contacts.

	You are notified of a new voicemail message (notification zone) Press the voicemail messages notification button in the top middle area of the screen
	OR Select the application
	History Voicemail Select the contact who has left a voice message
	OR On the homepage, press the voice mail key
	Information regarding your contact is displayed on the screen Play VM Listen to message
	Pause VM Pause while listening to message
	Stop VM Stop listening
	When you have played the message you can: Callback Call back sender of message
	Delete Delete the current message
	Delete all Delete all messages
	Call VM Consulting your voice
	Password Enter your password Follow the voice guide instructions

5.6 cancel the forwarding

Forward is active (forward key lit).

	Press the forward key
	OR Press your information area in the top left corner of the screen
	Routing
	None
	Back to homepage

5.7 Modify the forwarding

You can modify the forwards that you have programmed.

-  Press the forward key
OR
-  Press your information area in the top left corner of the screen
-  Routing
-  **Modify routing**
-  Select the forward to modify
-  Select the forward type to program
 - **Immediate forward to...**
 - **Forward if busy**
-  **Next**

■ Forward your calls to another set

-  **Other**
-  Enter the forward destination number
-  **Validate**
The forward is added to the list of predefined forwards
You can activate it immediately or later

■ Forward your calls to voicemail

-  **Voicemail**
-  **Save**
Save the forward
The forward is added to the list of predefined forwards
You can activate it immediately or later

5.8 Delete a forward

You can delete forwards that you have programmed.

-  Press the forward key
OR
-  Press your information area in the top left corner of the screen
-  **Delete routing**
-  Select the forward to delete
-  **Yes**
Confirm deletion

6.1 Change the keyboard type

While editing text, you can change the keyboard type to match the language you are writing: : AZERTY, QWERTY, QWERTZ, ...

 	<p>The keyboard is displayed on the screen</p> <p>Press the key symbolizing the keyboard type</p> <p>Select the keypad type (AZERTY, QWERTY, QWERTZ,...)</p> <p>Ok</p> <p>Validate your choice</p>
--	---

6.2 Delete a character

When editing a text you might have to correct it.

 	<p>Place the cursor after the text to delete by touching the screen</p> <p>Press the delete key of your keyboard</p>
--	--

▼ When you edit a text, you can delete several characters at once:

 	<p>Place the cursor before the first character to delete and, keeping your finger in contact with the screen, move to the last character to delete</p> <p>Press the delete key of your keyboard</p>
---	---

6.3 Write in uppercase

By default, the written characters are in lowercase.

    	<p>CAPS</p> <p>Press this key once</p> <p>The next character will be written in uppercase and then you will automatically switch to lowercase</p> <p>CAPS</p> <p>Press this key twice. The key associated light is on.</p> <p>Uppercase mode is used for all written characters</p> <p>CAPS</p> <p>To go back to lowercase mode, press the key again</p> <p>The keys associated light is off</p>
---	---

 This keys green light is on. Upper case mode is activated.

6.4 Write a number



NUM

Press this key once

Write a number, then the alphabetic mode is automatically activated



NUM

Press this key twice. The key associated light is on.

Write numbers



NUM

To go back to alphabetic mode, press the key again

The keys associated light is off



This keys green light is on. The numerical keyboard is locked.

6.5 Write special characters



Press this key once

The key associated light is on



Select a character

The special characters associated to the selected character are displayed



Select the desired character



Press this key again to go back to the standard keyboard

The keys associated light is off

7.1 Define the phone language

	Select the application Settings
	Device
	Phone configuration
	Language
	Select the language of your choice
	Ok
	Back to homepage

7.2 Favorites

Favorites : This application contains favorite contacts that you have selected in your personal directory (Address book).

Most frequently called contacts can be defined as a favorite.

	Select the application Contacts
	Select the contact to add to favorites
	Favorites The contact has been added to Favorites The key associated light is on

 The green light indicates that the contact has been assigned to Favorites

You can call your contact directly without selecting them from the personal directory.

	From the homepage : Favorites Select the correspondent
	OR
	Select the application Favorites
	Select the correspondent

■ To remove a contact from Favorites:

	Favorites The feature associated led goes off
---	---

7.3 Lock / unlock your telephone

Once the phone is locked, you can only call special numbers such as emergency, security or standard (3 max configured by the administrator).

• locking your terminal



Press the forward key

OR



Press your information area in the top left corner of the screen



UserInfo



Lock



Confirm :
Lock

Telephone locked.



A basic popup appears prompting you to answer or ignore the call. If you are on a call, you can only end the call.

From the homepage



Lock



Confirm :
Lock

Telephone locked

To lock your phone from the homepage, you must set the feature:



Select the application
Settings



Application



Lock



Enable or disable the feature

• Unlock your terminal



Enter your password to unlock the phone
The default password is 1515

7.4 Adjusting the audio functions



Select the application
Settings



Device



Audio



Your handset allows you to set different ringtones depending on the type of incoming call

On-site ringing

Off-site ringing

Special ringing

Event ringing



Choose ringer



Validate your choice

Ok

7.5 Activate/deactivate silent mode



Select the application
Settings



Device



Audio



Silent ringing

Enable or disable the feature

7.6 Ring tones

You can choose to have 1, 2 or 3 beeps before the ring



Select the application
Settings



Device



Audio



Beeps before ringing



Beeps before ringing


- **one beep** : One beep before ringing
- **two beep** : Two beeps before ringtone
- **three beep** : Three beeps before ringing
- **no beep** : Ring without beep




Ok

Validate your choice


7.7 Progressive ringing




7.8 Adjusting the ringer volume



7.9 Adjust ringer volume while a call arrives




7.10 Adjust the loudspeaker and the handset volume



7.11 Activate/deactivate key vibration

When you press one of your phone keys, a vibration confirms that the action has been taken into account by the system.


To activate or deactivate key vibration:




7.12 Activating headset mode

The side of the telephone features a headphone / external microphone socket. Contact your retailer for information on the various headphone models.

By default, the audio jack of your telephone can be used to connect a headset, hands-free kit or loudspeaker.



After selecting the accessory type, you must specify the jack accessory:



7.13 Install a bluetooth device (pairing)

You can use Bluetooth devices such as handsets or headsets with your phone.

To use your Bluetooth device, it must be paired to the set. To manage the pairing, the Bluetooth device must be in detectable mode. Refer to your Bluetooth device documentation to find out how to activate detectable mode.

	Your Bluetooth device is ready to be paired
	Select the application
	Settings
	Device
	Bluetooth
	Add device
	Scan
	The set scans for available Bluetooth devices
	Select the Bluetooth device to be paired
	Add the device to the device list
	Enter the devices PIN code
	Ok
	Bluetooth device connected

After pairing the Bluetooth accessory, you must define the accessory type in the audio settings.

	Select the application
	Settings
	Device
	Audio
	Accessory type
	BT
	Ok

After selecting the accessory type, you must specify the jack accessory:

	Jack accessory
	<ul style="list-style-type: none">• headset• handsfree• loudspeaker
	Ok

7.14 Hearing aid kit

If you are using your phone with a hearing device, you must install and activate the hearing aid device (HAC) to avoid hearing discomfort.

	Install the hearing aid kit using the instruction guide supplied
	Select the application Settings
	Device
	Audio
	Hearing aid Enable the feature : YES The hearing aid kit is activated

7.15 Activate the magnifying glass feature

 You must be identified as an administrator to be able to modify this feature

	Select the application Settings
	Device
	Phone configuration
	Admin
	Enter the administrator password
	Enable magnify Enable or disable the feature
	Back to homepage

7.16 Magnifying glass

The magnifying glass feature allows you to zoom in on the active area of the screen.

	Magnify
	The magnifying glass keyfeature lights green when activated The active area of the screen is magnified. You can move this area and zoom any part of the screen you want
	Press the feature key again to go back to normal view : Magnify

 The application bar cannot be magnified.

 The magnifying glass feature must be activated in order to be used.

7.17 Set an alarm

	Alarm
	Hour: Enter the alarm time
	Alarm sound: Select the melody of your choice
	Volume: Adjust the alarm volume
	Alarm status: Enable the feature
	The associated LED is on: the feature is enabled
	The icon is displayed (connectivity information zone)

 When the alarm bell rings, you can choose to repeat the alarm or turn it off.

7.18 File Manager

This application allows you to manage audio files, images, webradios and other media.

	Select the application My files
	Select the file type you want: <ul style="list-style-type: none">• Audio• Picture
	All available files of the selected type (on set or storage media connected on USB port) are displayed. You can also manage your phones multimedia files.

 The display time may take longer if the USB storage device contains too many files

7.19 Delete a file

	Select the application My files
	Select the file type you want: <ul style="list-style-type: none">• Audio• Picture
	Enter delete mode Delete
	Select the file to delete
	Confirm deletion Yes No
	Exit delete mode

 You cannot delete a file stored on an external device.

7.20 Rename a file

	Select the application My files
	Select the file type you want: <ul style="list-style-type: none">• Audio• Picture
	Select the file to rename
	Rename
	Enter the new file name
	Ok Apply
	OR
	Cancel the operation Cancel

 You cannot rename a file stored on an external device.

7.21 Copy a file from the external storage device to the phones internal memory

	Select the application My files
	Select the file type you want: <ul style="list-style-type: none">• Audio• Picture
	Filters Select the storage device
	Select the file to copy
	Copy

7.22 Listen to an audio file

	Select the application My files
	Audio
	Filters Display the files for the selected storage device (The phones internal memory or external storage device)
	Select the audio file
	The audio file plays automatically
	Pause: Pause
	Start listening again: Play
	Stop listening: Stop

 When released from the manufacturing plant, the audio files hosted on My IC Phone are Alcatel-Lucent property and can be used as is. When a Business Partner or End-User downloads MP3 files via a USB link, they are responsible for the Intellectual Property Right requirements related to such downloads.

7.23 Play all audio files



Select the application
My files



Audio



Filters

Display the files for the selected storage device (The phones internal memory or external storage device)



Play all

Listening of all audio files has started



Stop listening:
Stop all



Start listening again:
Play



Switch to next track:
Next



Listen to tracks in random order:
Random



When released from the manufacturing plant, the audio files hosted on My IC Phone are Alcatel-Lucent property and can be used as is. When a Business Partner or End-User downloads MP3 files via a USB link, they are responsible for the Intellectual Property Right requirements related to such downloads.

7.24 Phone wallpaper

You can change the wallpaper on your phone. The image must be stored in the set or on a USB storage device.

If the image is on the USB storage device, you must connect it to the phone:



Insert your USB device at the back of the phone

The icon is displayed (connectivity information zone)

Change the wallpaper:



Select the application
My files



Picture

The list of images on the USB device is also displayed



Filters

Display the files for the selected storage device



Select the image




Wallpaper

The selected image is set as wallpaper

7.25 Phone screensaver


You can change your phone screensaver to a default or a personal screensaver. The default screensaver uses predefined images. The personal screensaver uses images you have stored in your phone memory and set up in a screensaver pool.




You can set the screensaver timeout, the backlight timeout, the brightness when the backlight is on or off and the refresh images interval

- Add an image for your personal screensaver:

The images have to be stored in the phone memory



- Remove an image from your personal screensaver pool:



7.26 Customize the user picture

You can change the picture displayed in your personal information area in the top left corner of the screen. The image must be stored in the set or on a USB storage device.

If the image is on the USB storage device, you must connect it to the phone:

-  Insert your USB device at the back of the phone
-  The icon is displayed (connectivity information zone)
- Change the avatar:
 -  Select the application
My files
 -  **Picture**
The list of available pictures is displayed
 -  **Filters**
Display the files for the selected storage device
 -  Select the image
 -  **My picture**
The picture is updated

 The recommended size for the avatar is 100x100 pixels

7.27 Configure your homepage

You can configure your homepage according to your needs and calling habits.

You can display many applications on the homepage such as your history, contacts, favorite contacts, etc.

The phones Homepage can be in standard or preview mode

- Homepage in standard mode : Only application access keys are displayed on the homepage.



- Homepage in preview mode : The application access keys and some application previews are displayed on the homepage.



■ Choose the homepage layout

-  Select the application
Settings
-  **Application**
-  **Homepage**
-  **Homepage**
Standard : Homepage in standard mode
Preview : Homepage in preview mode
-  Back to homepage

■ Add or delete an application on the homepage

-  Select the application
Settings
-  **Application**
-  Select the application that you want to add to the homepage or delete from the homepage
-  Add or delete an application on the homepage
-  Back to homepage



Some applications cannot be added to the homepage as preview

■ Add a programmed key to the homepage (Homepage in standard mode)

-  Select the application
Settings
-  **Application**
-  **Homepage key**
-  **Add**
-  Programmed action selection
-  Follow the key programming instructions for the selected action
-  Enter the keys name
-  **Ok**
to confirm
-  Back to homepage
The programmed key is displayed on the homepage

■ Delete a programmed key from the homepage (Homepage in standard mode)



Select the application
Settings



Application



Homepage key



Enter delete mode.

Delete

The associated LED is on: the feature is enabled.



Programmed action selection



Press the key you want to delete



Ok

To confirm



Back to homepage

7.28 Change the theme of your phone



Select the application
Settings



Device



Phone configuration



Select the current theme in the configuration page

The available theme list is displayed on the screen



Select the desired new theme from the list



Ok

Confirm the selection



Changing the theme may take a few seconds

Guarantee and clauses

Safety Instructions

- Changes or modifications to the equipment not expressly approved by the party responsible for compliance could void the users authority to operate the equipment.
- **Intellectual Property Rights**
When released from the manufacturing plant, the audio files hosted on My IC Phone are Alcatel-Lucent property and can be used as is. When a Business Partner or End-User downloads MP3 files via a USB link, they are responsible for the Intellectual Property Right requirements related to such downloads.
- To limit the risk of interference, people with pacemakers must keep the wireless telephone away from their equipment (minimum distance of 15 cm).
- It is recommend to follow the standard acceptance procedures before using this equipment in human safety critical areas (hospitals...).
- The headset includes magnetic elements that may attract sharp metallic objects.
- There is a danger of explosion if the battery is replaced incorrectly - user only the battery with the reference 3GV28041AB (1.2V 1500 mAh) 3GV28041AB (1.2V 1500 mAh) (Bluetooth Handset only).
- Battery charge (Bluetooth Handset only) : Charge the battery for about 16 hours before initial use.

Regulatory Statements

EU/EFTA

This equipment is in compliance with the essential requirements of R & TTE Directive 1999/5/EC. The Declaration of Conformity may be obtained from your installer.

USA and Canada

This device complies with Part 15 of the FCC Rules and with RSS-210 of Industry Canada.

Exposure to Radio Frequency Signals.

This device has been designed and manufactured not to exceed the SAR (Specific Absorption Rate) radio frequency power transmission limits established by the different countries concerned. The SAR value for the Bluetooth handset is 0.09 W/kg (the globally accepted maximum limit being 1.6 W/kg).

User Instructions

Only use the handset in temperatures between -5 C to +45 C (23 F to 113 F).

This apparatus is Hearing Aid Compatible (HAC).

Acoustic shock protection

The acoustic level of the signal generated by the handset earpiece is less than 130 dBspl for a transient signal (123 dBspl for Australia) and less than 118 dBspl (rms) for a continuous signal (120 dBA for Australia) .

Directive 2003/10/EC specifying the risks inherent in noise at work

The ring contributes towards overall daily noise; at its maximum setting, the level is 105 dBA at 60 cm from terminal. To reduce the level, the following is recommended:

- reduce the setting (9 levels of 5 dB)
- program a progressive ring

This device can be used for indoor operation in all the countries; you must consult your installer for an outdoor usage.

Privacy

Privacy of communications may not be ensured when using the Bluetooth handset or any additional Bluetooth device

Disposal



The equipment must be returned to a collection point for electronic equipment waste disposal. Defective batteries must be returned to a collection point for chemical waste disposal.

Alcatel-Lucent, Lucent, Alcatel-Lucent and the Alcatel-Lucent logo are trademarks of Alcatel-Lucent. All other trademarks are the property of their respective owners. The information presented is subject to change without notice. Alcatel-Lucent assumes no responsibility for inaccuracies contained herein. Copyright © 2011 Alcatel-Lucent. All rights reserved